

# 1967 to 1970 Factory Drum Brake Distribution Block

A, B, C & E Body and Imperial

Rear Port of  
Master Cylinder  
Front Brakes

TOP

Right  
Front

Left  
Front

REAR

FRONT

Rear  
Brakes

Front Port of  
Master Cylinder  
(Rear Brakes)

OUTLET TO  
REAR BRAKE TUBE

INSERT

PLUG

NP16A

SPRING

OUTLET TO  
RIGHT  
FRONT  
BRAKE TUBE

SWITCH BODY

OUTLET TO LEFT  
FRONT BRAKE TUBE

PISTON SEAL "O" RING

SWITCH SEAL "O" RING

SWITCH ASSEMBLY

PISTON ASSEMBLY

**Hydraulic System Safety Switch (Sectional)**

BOTTOM



TRM 67-70 Factory Drum Brake Distribution Block

Phone: (817) 429-0105 Email: info@therammanINC.com Website: www.therammanINC.com